

TR4 Quick Start Tuning Guide

It is useful to have a TV listings magazine or another television to look at while you are tuning your set. Doing this will make it easier to identify stations when you find them.

I) Initial Setup (Auto-tune)



1. Put your TV aerial into the aerial socket. Connect the plug to the mains.
2. Switch the television on with the power button at the front of the set and with the remote using the top red standby button.
3. The first menu titled 'Language' will be displayed. On the remote press the **UP ARROW** to move the highlight on the menu up and the **DOWN ARROW** to move the highlight on the menu down.
4. Select English from the menu then press the **RIGHT HAND ARROW** to confirm.
5. The next menu will ask for the country of use. Select the desired country with the **DOWN ARROW** then press the **RIGHT HAND ARROW** to confirm.
6. The Televideo will autosearch for any stations it can find. When it has finished press **MENU** to return to the install menu, then press **MENU** again to return to the picture.
7. Browse through the channels numbers to make sure all the channels are tuned in and in the correct order.
8. If they are not in the correct order then you can move the station numbers by turning to page 7 of the instruction book.

II) Manual Tuning

1. Firstly, select the channel number that you wish to tune in. For example, if you need to tune in BBC1, press **1** on your remote control.
2. Press the **MENU** button and the main menu will appear
3. Move the highlight on the menu down to **INSTALL** using the **DOWN ARROW**.
4. Press the **RIGHT HAND ARROW** to access the install menu.
5. Move the highlight down to **MANUAL TUNING** using the **DOWN ARROW**.
6. Press the **RIGHT HAND ARROW** to access the manual tuning bar.
7. Press the **RIGHT HAND ARROW** again to search up the tuning band
8. **Please wait** will flash while the television searches.
9. When the television has finished searching 'please wait' will disappear from the screen and a picture will be displayed in the background.
10. Decide what channel the picture is by looking at your TV listings guide or another television. If the picture is the one you want (for example, you are on station 01 and you have a picture of BBC1) press **MENU**, otherwise press the **RIGHT HAND ARROW** again and repeat this step until you have the picture you require.
11. You will then be returned to the install menu. Press **MENU** again to return to the install menu. Press **MENU** again to return to the main menu and menu again to get the picture on screen.
12. Return to step 1 and repeat the process for all channels.

III) Naming Channels

Please turn to page 7 of the instruction book for details on how to name your channels.

****Note:**** There is no need to tune in a video station. Just press **PLAY** and your video will switch to the video channel automatically.

Customer Helpline 01422 263265